



INSTALLATION CHECKLIST

Use LEXEL sealant

- Entire perimeter of deck on top of joists – prevents wicking
- Drainage channel near house – prevents wind blowback
- Interlocking groove – whenever drainage channel is interrupted

Fastener placement

- Face screw only on starter and finish board – 2-1/2" Fin/Trim
- Fastening Wing – Field of Deck – 1-5/8" Fin/Trim

Mounting clip

- Mounting clip – just on the ends of each board

Spacers – 1/32" between boards

- Recommended when outside temp is below 70 degrees

Flashing goes on top of deck along any wall

- Recommended when outside temp is below 70 degrees

Pitch the deck minimum 1/8" per foot away from structure

Block all joists longer than 6-foot span

- Before installing decking, make sure deck is "in plane"
- Blocking helps prevent twisting and warping
- This is good practice for any composite deck

Gap of 3/16"

- Along the house and at any obstruction

Starter & finish board

- Rip groove wing for starter board
- Rip fastening wing for finish board
- You can rip the board anywhere along any septum for best fit
- The edge can be finished with a sander
- ArmorCap boards can be stained after sanded

Ventilation under the deck

- If a ceiling is installed under the deck, ventilation is required to prevent excessive heat and humidity build up which can negatively affect the treated lumber

Distributed by

AmeriLux International
1300 Enterprise Drive
De Pere, WI 54115-3193

www.amerilux.com
Toll Free: 888-602-4441
Email: info@amerilux.com

Manufactured by

DuxxBak Composite Decking
1518 S. Broadway St.
Green Bay, WI 54304